



Clipster Care & Best Practices

Follow these simple steps to keep your Clipster running smoothly and avoid warranty issues

1



Remove Clipster from the box and loosen blade tensioner

2



Always oil the blades before and during use - every 10 minutes is the recommendation

3



Turn on the clippers to prepare for clipping, gradually tighten the blades until they start clipping



DO NOT OVER-TIGHTEN THE BLADES

Why Blade Tension Matters

This will damage the Gear Wheel and lead to Motor failure

The Gear Wheel is designed to prevent Motor burnout by absorbing excessive strain

Maintenance & Servicing

Regular oiling and maintenance will extend the life of your Clipster

Blades can be sharpened or replaced by Mullinahone Co-op through your retailer/place of purchase

For servicing support contact your local retailer/place of purchase

Taking care of your Clipster ensures optimal performance and a longer lifespan!

